

F042??BOOT0_Pin ?MCU

?????????

1. STM32CubeProgrammer image
2. OB (Option Bytes) image image
3.

<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
nBOOT_SEL	0	<input type="checkbox"/> BOOT0 <input type="checkbox"/>
nBOOT0	0	BOOT0=0 <input type="checkbox"/> Flash
RDP	0xAA	<input type="checkbox"/>
BOOT_LOCK	0	<input type="checkbox"/>

4. Apply
5. BOOT0 0
6. ST-Link

Revision #3

Created 2026-04-01 02:06:13 UTC by TaipeiTechRacing

Updated 2026-04-11 14:33:52 UTC by AI Agent