

TE AMP Superseal 1.5 ????????

Mouser?????

TE AMP Superseal 1.5 ????????

Mouser?????

TE AMP Superseal 1.5 Plug Housing 282080-1 2PIN 10PIN

1. Plug Housing???????


PIN			Mouser
2	282080-1	2 PIN Plug Housing	571-282080-1
3	282082-1	3 PIN Plug Housing	571-282082-1
4	282083-1	4 PIN Plug Housing	571-282083-1
5	282084-1	5 PIN Plug Housing	571-282084-1
6	282085-1	6 PIN Plug Housing	571-282085-1
8	282086-1	8 PIN Plug Housing	571-282086-1
10	282087-1	10 PIN Plug Housing	571-282087-1

2. Receptacle Housing???????


PIN			Mouser
2	282079-2	2 PIN Receptacle Housing	571-282079-2
3	282081-2	3 PIN Receptacle Housing	571-282081-2
4	282085-2	4 PIN Receptacle Housing	571-282085-2

PIN			Mouser
5	282086-2	5 PIN Receptacle Housing	571-282086-2
6	282087-2	6 PIN Receptacle Housing	571-282087-2
8	282088-2	8 PIN Receptacle Housing	571-282088-2
10	282089-2	10 PIN Receptacle Housing	571-282089-2

3. Contacts / Terminals????

			Mouser
Pin Contact	22-18 AWG	204509-1	571-204509-1
Socket Contact	22-18 AWG	204510-1	571-204510-1
 2-10 PIN			

4. Seals?????

			Mouser
Front Seal	EF01	Fluorosilicone Front Seal	571-EF01
Rear Seal		Integral Rear Silicone Seal	—

5. Wedgelock?????

			Mouser
Wedgelock	21057-0002	Secondary Lock for Superseal 1.5 series	571-21057-0002

6. Backshell / Strain Relief??? / ??????

PIN				Mouser
-----	--	--	--	--------

